

# Brookstone®

---

## MightyMax® Tower Fan

MIGHTY POWERFUL.  
MIGHTY QUIET.



## CAUTION

- TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER. THERE ARE NO SERVICEABLE PARTS INSIDE.
- TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS UNIT TO RAIN OR MOISTURE.



The lightning flash with arrow-head symbol within an equilateral triangle is intended to alert the user to the presence of uninsulated “dangerous voltage” within the unit’s enclosure that may be of sufficient magnitude to constitute a risk of electric shock.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the unit.

## **IMPORTANT SAFETY INSTRUCTIONS**

All the safety and operating instructions should be read, adhered to and followed before the unit is operated.

### **DANGER**

To reduce the risk of electric shock, burns, fire or injury:

1. Always unplug the unit from the electrical outlet immediately after using.
2. Do not use while bathing or in a shower.
3. Do not place or store unit where it can fall or be pulled into a tub or sink.
4. Do not place in or drop into water or other liquid.
5. Do not reach for unit that has fallen into water. Unplug it immediately.
6. Care should be taken so that objects do not fall and liquids are not spilled onto the unit.

### **SAVE THESE INSTRUCTIONS**

## WARNING

1. When using electrical appliances, basic precautions should always be followed to reduce the risk of fire, electric shock and injury.
2. Use this fan only as directed in this manual. Non-recommended use may cause fire, shock or injury.
3. This fan is intended for personal use indoors. It is not designed for commercial, industrial or outdoor use.
4. Do not place fan in or near window. Avoid immersing fan, plug or cord in water/liquid. Do not spray with water/liquid.
5. This appliance has a polarized plug (one blade is wider than the other). This plug is designed to reduce the risk of shock by only fitting into a polarized outlet one way. If the plug doesn't fully fit in an outlet, try reversing the plug. If it still doesn't fit, contact a qualified electrician. Do not attempt to defeat this safety feature.
6. A loose plug/outlet connection may cause overheating and distortion of plug. Contact a qualified electrician to replace a loose or worn outlet.
7. Always turn the fan off and unplug it when it's not in use, when transporting it to another location and before cleaning.
8. When disconnecting fan, turn it off, grip the plug firmly and pull it from the wall outlet. Never pull it out by the cord.
9. Do not operate fan if the cord or plug is damaged, the unit is malfunctioning, has been dropped or is damaged in any way.
10. Do not operate your fan in the presence of flammable and/or explosive fumes.
11. Do not place the fan or any of its parts near an open flame, cooking appliance or heater.

12. Do not operate fan if housing has been removed or damaged.
13. Avoid contact with moving parts.
14. Close supervision is necessary when operating fan near children.
15. Operate fan on a dry, level surface.
16. Do not mount fan on a wall or hang it from the ceiling.
17. Use of attachments of any kind is not recommended.
18. If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.

## **WARNING**

To reduce risk of fire or shock, do not use this fan with any Solid-State Speed Control Device.

## **BATTERY PRECAUTIONS**

- Dispose of the old batteries properly. Do not dispose of the old batteries in a fire.
- Do not leave the batteries where a child or pet could play with or swallow them. If the batteries are swallowed, contact a physician immediately.
- The batteries may explode if mistreated. Do not attempt to recharge or disassemble the batteries.
- Use only fresh batteries of the required size and type. Do not mix old and new batteries, different types of batteries, or rechargeable batteries of different capacities.

# FAN OPERATION



## INSTALLING REMOTE BATTERIES

1. Slide battery cover off.
2. Install 2 AAA batteries (not included), according to polarity indicators inside the battery compartment.
3. Slide battery cover back on.

## SETTING UP THE FAN


Tighten the three wing nuts located on the underside of the base to the fan.

## POWERING THE FAN

Press  on either the unit or remote. The power light will remain lit when the unit is connected to the main power even if  has not been pressed.


**Note:** When using the remote, point it directly at the front of the fan to ensure proper signal transmission. The remote can operate up to 24 feet away from the fan. You will hear a beep from the fan and see illuminated lights on the fan.

## USING SPEED


Press SPEED  on either the unit or remote. Each time SPEED is pressed, the speed will continuously cycle through LOW, MEDIUM and HIGH. The speed will illuminate on the LED display.

## USING OSCILLATION

This fan is designed to oscillate 90° to efficiently cool large spaces.

Press  on either the unit or remote to power oscillation on.

The LED will illuminate.

Press  once again on either the unit or remote to power oscillation off.

The LED light will extinguish.

## USING MODE

Press MODE on either the unit or remote to cycle through NORMAL, NATURAL and SLEEP.


NORMAL—chosen speed and oscillation remain consistent


NATURAL—the three speeds vary randomly like a natural breeze

SLEEP—the three speeds vary randomly, including the unit shutting off for different periods of time throughout cycle.

## USING THE TIMER

This fan has four settings: one hour, two hours, four hours and eight hours.

Press TIMER  on unit or remote to cycle through different time settings.

This cycle will continuously repeat each time TIMER  is pressed.

## **CARE AND MAINTENANCE**

To clean the fan, unplug it and wipe the housing with a soft, damp cloth. Use a mixture of mild, non-abrasive detergent and water. Do not soak/immerse fan in water/liquid. Store in a dry place away from excessive heat.

Operating temperature range is 50°F to 115°F (10° to 46°F).

# ONE (1) YEAR LIMITED WARRANTY

Brookstone® warrants this product against defects in materials and/or workmanship under normal use for a period of ONE (1) YEAR from the date of purchase by the original purchaser ("Warranty Period"). If a defect arises and a valid claim is received within the Warranty Period, at its option, Brookstone will either 1) repair the defect at no charge, using new or refurbished replacement parts, or 2) replace the product with a new product that is at least functionally equivalent to the original product, or 3) provide a store credit in the amount of the purchase price of the original product. A replacement product or part, including a user-installable part installed in accordance with instructions provided by Brookstone, assumes the remaining warranty of the original product. When a product or part is exchanged, any replacement item becomes your property and the replaced item becomes Brookstone's property. When a store credit is given, the original product must be returned to Brookstone and becomes Brookstone's property.

**Obtaining Service:** To obtain warranty service, call Brookstone Limited Warranty Service at 1-800-292-9819. Please be prepared to describe the product that needs service and the nature of the problem. A purchase receipt is required. All repairs and replacements must be authorized in advance. Service options, parts availability and response times will vary. You are responsible for delivery and the cost of delivery of the product or any parts to the authorized service center for replacement, per our instructions.

**Limits and Exclusions:** Coverage under this Limited Warranty is limited to the United States of America, including the District of Columbia and the U.S. Territories of Guam, Puerto Rico, and the U.S. Virgin Islands. This Limited Warranty applies only to products manufactured for Brookstone that can be identified by the "Brookstone" trademark, trade name, or logo affixed to them or their packaging. The Limited Warranty does not apply to any non-Brookstone products. Manufacturers or suppliers other than Brookstone may provide their own warranties to the purchaser,

but Brookstone, in so far as permitted by law, provides these products “as is.” This warranty does not apply to: a) damage caused by failure to follow instructions relating to product’s use or the installation of components; b) damage caused by accident, abuse, misuse, fire, floods, earthquake or other external causes; c) damage caused by service performed by anyone who is not a representative of Brookstone; d) accessories used in conjunction with a covered product; e) a product or part that has been modified to alter functionality or capability; f) items intended to be periodically replaced by the purchaser during the normal life of the product including, without limitation, batteries or light bulbs; g) any product sold “as is” including, without limitation, floor demonstration models and refurbished items; or h) a product that is used commercially or for a commercial purpose.

**BROOKSTONE SHALL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THIS PRODUCT, OR ARISING OUT OF ANY BREACH OF THIS WARRANTY. TO THE EXTENT PERMITTED BY APPLICABLE LAW, BROOKSTONE DISCLAIMS ANY AND ALL STATUTORY OR IMPLIED WARRANTIES, INCLUDING, WITHOUT LIMITATION, WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND WARRANTIES AGAINST HIDDEN OR LATENT DEFECTS. IF BROOKSTONE CANNOT LAWFULLY DISCLAIM STATUTORY OR IMPLIED WARRANTIES, THEN TO THE EXTENT PERMITTED BY LAW, ALL SUCH WARRANTIES SHALL BE LIMITED IN DURATION TO THE DURATION OF THIS EXPRESS WARRANTY.**

Some states disallow the exclusion or limitation of incidental or consequential damages or how long an implied warranty lasts, so the above exclusions or limitations may not apply to you. This warranty gives you specific legal rights and you may also have other rights, which vary from state to state.

# Brookstone®

A WORLD OF INNOVATION

Since 1965, people have come to Brookstone to see what's new, discover smart solutions to everyday problems—and have some fun. At Brookstone, we believe there's always a better way to do things. And we created a world of innovation to prove it.

Merrimack, New Hampshire USA 03054 • 800-846-3000 • [www.Brookstone.com](http://www.Brookstone.com)

371393