



Brookstone®

5-Piece Grill Tool Set
WITH DIGITAL THERMOMETER

TABLE OF CONTENTS

Warnings and Cautions	1
Location of Fork Parts and Controls.....	3
Installing the Battery in the Fork.....	3
Using the Thermometer.....	4
Temperature Guidelines.....	5
Using the Timer.....	6
Using the LED Light.....	6
Care and Maintenance.....	7
Specifications.....	7
Warranty.....	8

WARNING

- Examine brush before each use. Discontinue use if bristles are loose, damaged, missing, or show excessive wear. Carefully examine cooking surface for loose bristles before cooking.
- Close supervision is necessary when each unit of this set is used by or near children or mentally disabled individuals. Adult supervision is required.
- Use this unit only for its intended use as described in this manual.
- The digital fork is not intended for use as an oven thermometer or grill surface thermometer. The thermometer is designed to measure internal meat temperature and has an operational range between 32°F to 266°F(0°C to 130°C). Exposing the probe tip to temperatures above 266°F (130°C) could cause damage to the temperature sensor.
- This set of tools has sharp blades and sharp tips. Use with caution.
- Stainless steel meat probe will become extremely hot during use. Remove probe from meat and allow to cool.

BATTERY PRECAUTIONS

- Dispose of used batteries properly. Do not dispose of batteries in a fire.
- Do not leave the batteries where a child or pet could play with or swallow them. If the batteries are swallowed, contact a physician immediately.
- The batteries may explode if mistreated. Do not attempt to recharge or disassemble the batteries.
- Use only fresh batteries of the required size and type. Do not mix old and new batteries, different types of batteries, or rechargeable batteries of different capacities.

FCC INFORMATION

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B Digital Device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.


If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the distance between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This equipment may not cause harmful interference.
2. This equipment must accept any interference received, including interference that may cause undesired operation.

LOCATION OF FORK PARTS AND CONTROLS




INSTALLING THE BATTERY IN THE FORK

1. Remove the battery compartment cover from the back of the fork handle by pressing the tab at the bottom of the battery compartment cover.
2. Insert 2 AAA 1.5V batteries (included), following the polarity indicators.
3. Replace the battery compartment cover.

USING THE THERMOMETER

1. Locate the switch on the back of the fork handle and slide it to the THERMO position.
2. Press any button to turn on the digital display.
3. Press the °C/°F button to select Celsius or Fahrenheit temperature readings.
4. Press the UP or DOWN arrow to set the target temperature. Refer to the chart on Page 5 for temperature guidelines.
5. To test the temperature, remove the protective covering from the fork probe tips and insert the fork probe tips into the thickest part of the meat. Avoid touching bone or heavy fat areas. Wait a few seconds and view the meat temperature.
6. Repeat temperature readings periodically until the target temperature is reached. For accurate temperature readings, make sure the probe tips do not protrude through the meat.
7. An alarm sounds when the target temperature is reached. Shut off is automatic.



TEMPERATURE GUIDELINES

FOOD	PREPARED	TEMPERATURE
Beef	Rare	120°F / 49°C
	Medium Rare	130°F / 55°C
	Medium	140°F / 60°C
	Medium Well	150°F / 66°C
	Well Done	160°F / 71°C
Lamb	Medium	145°F / 63°C
	Well Done	160°F / 71°C
Veal	Medium	145°F / 63°C
	Well Done	160°F / 71°C
Pork	Medium	145°F / 63°C
	Well Done	160°F / 71°C
Turkey	Well Done	165°F / 74°C
Chicken	Well Done	165°F / 74°C
Hamburger	Medium	140°F / 60°C
	Medium Well	150°F / 66°C
	Well Done	160°F / 71°C
Fish	Well Done	145°F / 63°C


USING THE TIMER

1. Locate the switch on back of the fork handle and move to TIMER position.
2. To set a countdown time press the "M" (for minutes) and/or "S" (for seconds) button(s).
3. Press the START/STOP button to begin countdown.
4. If no countdown time is set, press the START/STOP to count up.
5. To clear the timer, press the START/STOP button to pause countdown, then press both the "M" and "S" button(s). at the same time to reset to zero.
6. Once a countdown has finished, the unit will beep.
7. To stop the alarm, press the START/STOP button again or move the switch on the back of the fork handle to the "THERMO" position.

NOTE: The timer will count up or down from 99:59.

USING THE LED LIGHT

Locate the ON/OFF switch on the side of the fork. Slide down to turn the light ON and slide up to turn the light OFF.



CARE AND MAINTENANCE

- Not all parts of this set are dishwasher safe. Hand wash tools and fork probes using only mild soap and hot water. Rinse thoroughly. Dry completely with a soft cloth. DO NOT splash or submerge LCD in water.
- Avoid long-term contact with corrosives.
- Do not use metallic brushes or sponges to clean.
- Examine the brush bristles after use. Discontinue use if bristles are loose, damaged, missing, or show excessive wear.

SPECIFICATIONS

Weight.....	Approx. 3.13 lbs (Approx. 1.4 kg)
Batteries.....	2 AAA 1.5V
Temperature Measuring Range.....	32°F to 266°F (0°C to 130°C)
Timer.....	Max 99 minutes 59 seconds

ONE (1) YEAR LIMITED WARRANTY

Brookstone® warrants this product against defects in materials and/or workmanship under normal use for a period of ONE (1) YEAR from the date of purchase by the original purchaser ("Warranty Period"). If a defect arises and a valid claim is received within the Warranty Period, at its option, Brookstone will either 1) repair the defect at no charge, using new or refurbished replacement parts, or 2) replace the product with a new product that is at least functionally equivalent to the original product, or 3) provide a store credit in the amount of the purchase price of the original product. A replacement product or part, including a user-installable part installed in accordance with instructions provided by Brookstone, assumes the remaining warranty of the original product. When a product or part is exchanged, any replacement item becomes your property and the replaced item becomes Brookstone's property. When a store credit is given, the original product must be returned to Brookstone and becomes Brookstone's property.

Obtaining Service: To obtain warranty service, call Brookstone Limited Warranty Service at 1-800-292-9819. Please be prepared to describe the product that needs service and the nature of the problem. A purchase receipt is required. All repairs and replacements must be authorized in advance. Service options, parts availability and response times will vary. You are responsible for delivery and the cost of delivery of the product or any parts to the authorized service center for replacement, per our instructions.

Limits and Exclusions: Coverage under this Limited Warranty is limited to the United States of America, including the District of Columbia and the U.S. Territories of Guam, Puerto Rico, and the U.S. Virgin Islands. This Limited Warranty applies only to products manufactured for Brookstone that can be identified by the "Brookstone" trademark, trade name, or logo affixed to them or their packaging. The Limited Warranty does not apply to any non-Brookstone products. Manufacturers or

suppliers other than Brookstone may provide their own warranties to the purchaser, but Brookstone, in so far as permitted by law, provides these products "as is." This warranty does not apply to: a) damage caused by failure to follow instructions relating to product's use or the installation of components; b) damage caused by accident, abuse, misuse, fire, floods, earthquake or other external causes; c) damage caused by service performed by anyone who is not a representative of Brookstone; d) accessories used in conjunction with a covered product; e) a product or part that has been modified to alter functionality or capability; f) items intended to be periodically replaced by the purchaser during the normal life of the product including, without limitation, batteries or light bulbs; g) any product sold "as is" including, without limitation, floor demonstration models and refurbished items; or h) a product that is used commercially or for a commercial purpose.

BROOKSTONE SHALL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THIS PRODUCT, OR ARISING OUT OF ANY BREACH OF THIS WARRANTY. TO THE EXTENT PERMITTED BY APPLICABLE LAW, BROOKSTONE DISCLAIMS ANY AND ALL STATUTORY OR IMPLIED WARRANTIES, INCLUDING, WITHOUT LIMITATION, WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND WARRANTIES AGAINST HIDDEN OR LATENT DEFECTS. IF BROOKSTONE CANNOT LAWFULLY DISCLAIM STATUTORY OR IMPLIED WARRANTIES, THEN TO THE EXTENT PERMITTED BY LAW, ALL SUCH WARRANTIES SHALL BE LIMITED IN DURATION TO THE DURATION OF THIS EXPRESS WARRANTY.

Some states disallow the exclusion or limitation of incidental or consequential damages or how long an implied warranty lasts, so the above exclusions or limitations may not apply to you. This warranty gives you specific legal rights and you may also have other rights, which vary from state to state.

Find thousands more
great ideas online

Brookstone®

322803

© Brookstone 2017

Merrimack, New Hampshire USA 03054 • 800-846-3000 • Brookstone.com