

Your grill isn't
afraid of the
dark any more

Brookstone®

BBQ Grill Light
FOR GREAT GRILLING AT NIGHT



TABLE OF CONTENTS

Warnings and Battery Precautions	1
Location of Parts	2
Inserting the Batteries.....	3
Mounting the Light.....	3
Powering the Light.....	3
Using the Timer.....	4
Replacing the Batteries	4
Care and Maintenance	4
Specifications.....	4
Warranty	5-6

WARNING


- Do not attempt to disassemble the unit. There are no user-serviceable parts inside.
- Avoid grease flare-ups.

BATTERY PRECAUTIONS

- Dispose of the old batteries properly. Do not dispose of the old batteries in a fire.
- Do not leave the batteries where a child or pet could play with or swallow them. If the batteries are swallowed, contact a physician immediately.
- The batteries may explode if mistreated. Do not attempt to recharge or disassemble the batteries.
- Use only fresh batteries of the required size and type. Do not mix old and new batteries, different types of batteries, or rechargeable batteries of different capacities.

LOCATION OF PARTS

1. Mounting Clamp Knob
2. Mounting Clamp
3. On/Off Button
4. Timer Button
5. Light Hood
6. Battery Cover



BBQ GRILL LIGHT OPERATION

INSERTING THE BATTERIES

1. Turn the BATTERY COVER, located on the side of the light, counter-clockwise and remove.
2. Insert four D batteries (not included) with the positive sides facing up.
3. Replace the BATTERY COVER and push down and turn clockwise to tighten.

MOUNTING THE LIGHT

1. Open the MOUNTING CLAMP by turning the MOUNTING CLAMP KNOB counter-clockwise.
2. Place the MOUNTING CLAMP over your grill handle or the lip of a nearby side table.
3. Tighten the MOUNTING CLAMP by turning the MOUNTING CLAMP KNOB clockwise and secure it in place.
4. Adjust the angle of the light by moving the head up or down.


Note: Do not place the unit within two feet of the exposed cooking surface. The excess heat may cause the unit to overheat, malfunction or melt.

POWERING THE LIGHT

1. Press the ON/OFF BUTTON  to turn the light on.
2. Press the ON/OFF BUTTON  again to turn the light off.

USING THE TIMER

1. Press the **TIMER BUTTON** .
2. The light illuminates for six minutes, then shuts off automatically.

Note: Each press of the **TIMER BUTTON**  resets the timer for six minutes.

REPLACING THE BATTERIES

Replace batteries when any of the following conditions occur:

- Bulbs do not light.
- Bulbs start to dim.

Note: The light bulbs are **LED** and do not need replacement. If one or more bulbs stop working, replace the batteries.

CARE AND MAINTENANCE

- Wipe BBQ Grill Light with a damp cloth to clean.
- Do not use alcohol-based or harsh abrasives on any part of the BBQ Grill Light.
- Do not submerge the BBQ Grill Light in water.

SPECIFICATIONS

Overall Size.....	11.75" x 8.25" x 2.75"
Power.....	4 D Batteries
Bulb Type.....	LED (Light Emitting Diode)
Bulb Lifespan.....	Approximately 100,000 Hours

ONE (1) YEAR LIMITED WARRANTY

Brookstone® warrants this product against defects in materials and/or workmanship under normal use for a period of ONE (1) YEAR from the date of purchase by the original purchaser (“Warranty Period”). If a defect arises and a valid claim is received within the Warranty Period, at its option, Brookstone will either 1) repair the defect at no charge, using new or refurbished replacement parts, or 2) replace the product with a new product that is at least functionally equivalent to the original product, or 3) provide a store credit in the amount of the purchase price of the original product. A replacement product or part, including a user-installable part installed in accordance with instructions provided by Brookstone, assumes the remaining warranty of the original product. When a product or part is exchanged, any replacement item becomes your property and the replaced item becomes Brookstone’s property. When a store credit is given, the original product must be returned to Brookstone and becomes Brookstone’s property.

Obtaining Service: To obtain warranty service, call Brookstone Limited Warranty Service at 1-800-292-9819. Please be prepared to describe the product that needs service and the nature of the problem. A purchase receipt is required. All repairs and replacements must be authorized in advance. Service options, parts availability and response times will vary. You are responsible for delivery and the cost of delivery of the product or any parts to the authorized service center for replacement, per our instructions.

Limits and Exclusions: Coverage under this Limited Warranty is limited to the United States of America, including the District of Columbia and the U.S. Territories of Guam, Puerto Rico, and the U.S. Virgin Islands. This Limited Warranty applies only to products manufactured for Brookstone that can be identified by the “Brookstone” trademark, trade name, or logo affixed to them or their packaging. The Limited Warranty does not apply to any non-Brookstone products. Manufacturers or

suppliers other than Brookstone may provide their own warranties to the purchaser, but Brookstone, in so far as permitted by law, provides these products “as is.” This warranty does not apply to: a) damage caused by failure to follow instructions relating to product’s use or the installation of components; b) damage caused by accident, abuse, misuse, fire, floods, earthquake or other external causes; c) damage caused by service performed by anyone who is not a representative of Brookstone; d) accessories used in conjunction with a covered product; e) a product or part that has been modified to alter functionality or capability; f) items intended to be periodically replaced by the purchaser during the normal life of the product including, without limitation, batteries or light bulbs; g) any product sold “as is” including, without limitation, floor demonstration models and refurbished items; or h) a product that is used commercially or for a commercial purpose.

BROOKSTONE SHALL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THIS PRODUCT, OR ARISING OUT OF ANY BREACH OF THIS WARRANTY. TO THE EXTENT PERMITTED BY APPLICABLE LAW, BROOKSTONE DISCLAIMS ANY AND ALL STATUTORY OR IMPLIED WARRANTIES, INCLUDING, WITHOUT LIMITATION, WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND WARRANTIES AGAINST HIDDEN OR LATENT DEFECTS. IF BROOKSTONE CANNOT LAWFULLY DISCLAIM STATUTORY OR IMPLIED WARRANTIES, THEN TO THE EXTENT PERMITTED BY LAW, ALL SUCH WARRANTIES SHALL BE LIMITED IN DURATION TO THE DURATION OF THIS EXPRESS WARRANTY.

Some states disallow the exclusion or limitation of incidental or consequential damages or how long an implied warranty lasts, so the above exclusions or limitations may not apply to you. This warranty gives you specific legal rights and you may also have other rights, which vary from state to state.

Find thousands more
great ideas online

Brookstone[®]

798392

Merrimack, New Hampshire USA 03054 • 800-846-3000 • Brookstone.com