

Brookstone®

This battery is intended for use with the FlightForce™ Micro Hover Drone.

LI-PO Battery Warning

This battery must be recycled or disposed of properly. Contact your local waste management office for information on battery recycling or disposal.

Use only the cable supplied with the drone to recharge the battery. Improper charging may damage the battery and the device.

Do not attempt to open the rechargeable battery or battery pack. There are no serviceable parts inside.

Keep the battery out of reach of children. If swallowed, consult a physician immediately.

Do not expose the battery to high temperatures or dispose of battery in a fire as it may explode. The battery may also explode if damaged.


Do not use the battery if it has been damaged, or if it is swollen, leaking, or producing an odor. Avoid direct contact with the electrolytic material in the battery. (BC)

CHARGING THE BATTERY

Charge the battery before first use. A full charge takes approximately 35 minutes.

To charge the battery:

1. Connect the charging cable (supplied with the drone) to the Charging/Power Connector on the battery.



- You can charge the battery while it is in its compartment on the underside of the drone, or remove it from the drone before charging.
2. Insert the charging cable's USB connector into a USB port on an active device, such as a computer, USB adapter, or power bank.
 3. The Charging Indicator in the USB end of the charging cable is red while charging, and turns off when the battery is fully charged.

327026

© Brookstone 2017

Brookstone.com | 1-800-846-3000
1 Innovation Way, Merrimack, NH 03054